



Product indicated for indoor areas.

- 1° - Pass the socket wire through the canopy central hole, and instal in the electrical network
- 2°- Fix the canopy on the ceiling with the bushings and screws

- 3°- Press the frame on the canopy until fit in canopy spring letting the socket outside.
- 4° - Fit the lamps

- 5°- Put the lamp inside the support and fit the lamp spring.
- 6°- Push everything up until it get fixed.

Put the lamp between springs as shown in the image.

ML-2240 4 5/8" x 4 5/8" x 4 1/8" GU10 120/277V
ML-2241 4 5/8" x 8 5/8" x 4 1/8" 2xGU10 120/277V

Power Max:7W **Weight:**0.90 lbs
Power Max:7W **Weight:**1.39 lbs

Attention

Follow the instructions to ensure proper and safe operation. We recommend that the installation be done by a qualified professional. Recessed ceiling installation requires rigid support point attachment and special installations require special attachment.

Important

Lamps, transformers, and reactors are not included with the product except as noted. Failure to follow the instructions in the manual could result in accidents and loss of warranty. Do not adjust springs and brackets unless otherwise indicated.
 Warranty: 1 year for product and 5 years for Led and Driver.

Cleaning and Maintenance

Before any action turn off the electric current. Clean only with water dampened flannel, never use chemicals or abrasives. The materials that make up the product are non-toxic.