



- 1° Make the niche in the ceiling, according to the measurements below.
- 2° Make electrical connection.
- 3° Press the lamp base in the niche, it will be fixed through the springs.

- 4° Use a ruler to level the rim with the ceiling. For item ML-2209, follow the note on the side.
- 5° Fill the gaps and recess with plaster and finish with plaster.
- 6° Place the lamps. Do not use incandescent lamps.

Only for item ML-2209 after leveling the rim, remove the support plates and discard them.

- 7° To place the diffuser, flex it with your hands and insert it at an angle into the piece. Still without releasing it, bring it to the edge position, then release it gently leaving it supported inside the piece by the tabs.

**ML-2207** Ø13 2/3" x 5 5/16" 4 x E26 120/277V  
**ML-2209** Ø23 1/2" x 5 5/16" 8 x E26 120/277V

**Power Max:** Max 11W each lamp (A19)  
**Power Max:** Max 11W each lamp (A19)

**Weight:** 3.39 lbs  
**Weight:** 7.23 lbs

**Cutting area:** Ø15 1/8"  
**Cutting area:** Ø25 1/4"

**Product indicated for indoor areas.**

### Attention

Follow the instructions to ensure proper and safe operation. We recommend that the installation be done by a qualified professional. Recessed ceiling installation requires rigid support point attachment and special installations require special attachment.

### Important

Lamps, transformers, and reactors are not included with the product except as noted. Failure to follow the instructions in the manual could result in accidents and loss of warranty. Do not adjust springs and brackets unless otherwise indicated.  
 Warranty: 1 year for product and 5 years for Led and Driver.

### Cleaning and Maintenance

Before any action turn off the electric current. Clean only with water dampened flannel, never use chemicals or abrasives. The materials that make up the product are non-toxic.